


ASSEMBLY HARDWARE



- A. Padded transport bag
- B. Panel bag
- C. Showcase counter with 2 shelves
- D. 8 Clear PVC panels
- E. Hook and loop tabs



ASSEMBLY



Assembly

1. Place the collapsed showcase counter on the ground. Ensure that the circular tabletop is on the top, facing upwards.
2. Turn the tabletop clockwise (to the right).
3. Make sure all of the latches are pushed up to prevent them from getting caught.
4. Turn until all four of the aluminum struts are fully taut.
5. Push down on all 8 latches to fasten them to the struts to secure the display.
6. Insert one side of the panels so that the rounded cutouts sit up against the slots behind the struts. Flex the panel in a half-circle so that the rounded cutouts on the other side of the panel match up with the cutouts behind the opposite strut.
NOTE: To avoid getting fingerprints on the clear plastic panels, use gloves when installing panels.
7. Showcase counter is fully assembled.
8. For the Showcase Tower, place and align hook and loop tabs to connect counters together.
9. Follow instructions 1-5 for both counter pieces. Install panels on bottom counter and on the higher level on the upper counter, leaving the lower level open for easier handling (Image 6). With the recommended two people, hold the counter with the hook tabs at the bottom on top of the other.
10. Repeat step 6 for the lower level of the top counter. Showcase Tower is complete.

Disassembly (not shown)

1. Remove the plastic panels by flexing them and pulling them outward.
2. Release the latches by pushing upward until the latch pops free (Image 3).
3. Turn the tabletop counterclockwise (to the left) and push down until the aluminum struts are fully collapsed. Store counter and panels in bags.



DISCLAIMER: User must read and observe assembly instructions. If this is not done correctly it may result in damage to the unit, injury, or death, and all warranties will be void. All warranties will be void if this product is used with any print or hardware not produced by us. Never sit or stand on the table/tower. Do not place a direct heat source on or near the table/tower surface. Watch out for pinch points when folding/unfolding. Do not use if display has visible structure damage. Weight limit countertop: 45.0lb evenly distributed. Weight limit shelf: 10.0lb evenly distributed.

